




CDEEP
IIT Bombay

MOS Capacitor is a simple device which can be used to evaluate almost all electrical properties of SiO₂-Si system.



$$\epsilon = K \epsilon_0$$


(i) Vgs is -ve (Accumulation Mode) EE 669 L 13 / Slide 08

Electrons are repelled from SiO₂-Si interface. This creates excess holes at that place. Thus interface accumulates holes (+tive charge). -Qm at the metal = Qsi at surface (Gauss's law Qm + Qs = 0)

The capacitor has now like metal-oxide-metal structure with $C = C_{ox} \cdot A$ where $C_{ox} = \frac{\epsilon_{ox}}{t_{ox}} \text{ F/cm}^2$

(ii) Vgs is +tive but small (Depletion Mode)





In getting Gauss's law statement, we assume here that there are no charges in Oxide and hence $\epsilon_{ox} E_{ox} = \epsilon_s E_s$ (Discontinuity) is followed.




CDEEP
IIT Bombay

EE 669 L 13 / Slide 09

With V_{gs} small positive, we have $Q_m + \delta$ small. Gauss's law not want -ve charges to reach surface of Silicon. Direction of Electrical field forces holes to move downwards leaving -ve acceptor ions at Si-surface. That is surface region gets depleted of free carriers, and one observes Depletion Region. The depletion width $\propto \sqrt{V_{gs}}$

Initially due to small V_{gs} , $\propto 1/\sqrt{N_a}$ $x_d = \sqrt{\frac{2\epsilon_s \phi_0}{e N_a}}$
 Electric field E_s is also small. Hence Generation of e-h pair in D-layer, finally recombine there itself.

We have now two capacitors in series



Hence net $C = \frac{C_{ox}' C_s'}{C_{ox}' + C_s'}$

Obviously net C now will be less than C_{ox}' as was observed in Accumulation case.

EE 669 L 13 / Slide 10

iii) Hence increase in $+V_{gs}$ will decrease C_s as depletion width will enhance. This means C_{net} will decrease further with V_{gs} increasing.





iii) V_{gs} positive and large (Inversion)


At some reasonably high V_{gs} , Electric Field in Semiconductor region becomes sufficiently ^{high}, that is E_s become large enough, then generated electron-hole pairs experience large force and they separate. Holes move along the field come out of Depletion layer and are collected at sub-ground



CDEEP
IIT Bombay



more towards surface. The starting wafer has p-type doping, so without Bias Silicon surface was p-type with hole conc. = N_a^-




However now electrons start piling up at Si-surface opposite to starting case (hole conc.). This case is called Inversion.

Since excess V_{gs} now creates free inversion electrons, Depletion layer remains constant and hence net Capacitor also becomes const independent of V_{gs} .

The value of V_{gs} (Positive for P-sub), at which inversion electron conc. n is equal to starting p-conc, is called Threshold Voltage V_T .

$$V_{GS} = V_{ox} + \psi_s$$



CDEEP
IIT Bombay

EE 669 L 13 / Slide 12

Ideally
$$V_T = \pm 2\phi_F - \frac{\pm Q_{Bulk}}{C_{ox}}$$

where Q_{Bulk} is Depletion charge density

$$= +q N_d^+ x_{dmax}$$

$$\text{or } = -q N_a^- x_{dmax}$$

and $q\phi_F$ is Fermi Energy & $\phi_F = \pm \frac{kT}{q} \ln \frac{N_a \text{ (or } N_d)}{n_i}$
 $= E_i - E_F$

In real life



CDEEP
IIT Bombay

EE 669 L 14 / Slide

$$V_T = \phi_{ms} \pm 2\phi_F - \frac{Q_{ox}}{C_{ox}} - \frac{\pm Q_B}{C_{ox}}$$


$\phi_{ms} = \phi_m - \phi_s$ Work function Difference
between Metal & Semiconductor

Q_{ox} = fixed Oxide Charge (~~Always~~ Always Positive)

$$\phi_F = \text{Fermi Potential} = \frac{E_i - E_F}{q}$$

MOS Sat current \Rightarrow

$$I_{Dsat} = \frac{1}{2} \mu C_{ox} \left(\frac{W}{L} \right) [(V_{GS} - V_T)^2] [1 + \lambda V_{DS}]$$





CDEEP
IIT Bombay


EE 669 L 14 / Slide _____

Fixed charge Q_{ox} :-

within 25 \AA of Si-SiO₂

surface, we observe that a +tive charges exist and their Density is almost constant.

This Charge Density Q_{ox} (C/cm^2) is attributed to fact that at the end of oxidation time, interface proximity leaves incomplete oxidation and may end up in $\text{Si}^{3+}-\text{O}$ bonds, which results in Fixed Positive charge. $Q_{ox\text{Fixed}} \approx 2 \cdot (10^{10} - 10^{11}) \text{ col./cm}^2$




Mobile Charge :- Sodium ions (Na^+) are omnipresent in SiO_2 and they can drift in Oxide under electric field. Mobile charge density Q_{Mobile} is varying function

Interface Charge

Any Solid Surface, leaves dangling bonds which are not satisfied.

D.B.



Silicon Surface too, however cleaned (Virgin surface), also have these

Dangling Bonds present. These are called Schokly or Tamm States. The number of such States could be as high $10^{20} / \text{cm}^2$

During Oxidation of Silicon, Oxygen tries to Bond with Silicon through these bonds, reducing their charge density. However not all bonds are satisfied and leaves interface charge density of the order of $q \cdot x(10^{10} - 10^{11}) \text{ col/cm}^2$. Number Density is termed D_{it}

$$\therefore Q_{it} = q \cdot D_{it}.$$



CDEEP
IIT Bombay

EE 669 L 14 / Slide

Influence of Interface charges of MOS

Device characteristics.

For a MOS Capacitor (or MOS Transistor) the threshold voltage V_T is given by

$$V_T = \phi_{ms} \pm 2\phi_F - \frac{Q_{ox} + Q_{it} + Q_m}{C_{ox}} - \frac{\pm Q_{Bulk}}{C_{ox}}$$

where $\phi_{ms} = \phi_m - \phi_s$

$$Q_{Bulk} = \pm q (N_a \text{ or } N_d) X_{dmax}$$

$$2\phi_F = 2 \cdot \text{Fermi Potential} = \frac{2kT}{q} \ln \frac{N_a \text{ (or } N_d)}{n_i}$$

$$X_{dmax} = \sqrt{\frac{2K_s \epsilon_0 \psi_s}{q N_a \text{ (or } N_d)}}$$

ψ_s is surface potential and is $= 2\phi_F$ at inversion



CDEEP
IIT Bombay

EE 669 L 14 / Slide _____